

SPE

Service Instructions



Copyright by Carl Valentin GmbH / 7987025.0910

Information on the scope of delivery, appearance, performance, dimensions and weight reflect our knowledge at the time of printing.

We reserve the rights to make modifications.

All rights, including those regarding the translation, are reserved.

No part of this document may be reproduced in any form (print, photocopy or any other method) or edited, copied or distributed electronically without written permission from Carl Valentin GmbH.

Due to the constant further development of our devices discrepancies between manual and device can occur.

Please check www.carl-valentin.de for the latest update.

Trademarks

All named brands or trademarks are registered brands or registered trademarks of their respective owners and may not be separately labelled. It must not be concluded from the missing labelling that it is not a registered brand or a registered trademark.

Carl Valentin print modules comply with the following safety guidelines:

- CE** EG Low-Voltage Directive (73/32/EEC)
- EG Electromagnetic Compatibility Directive (89/336/EEC)



Carl Valentin GmbH

Postfach 3744
78026 Villingen-Schwenningen
Neckarstraße 78 – 86 u. 94
78056 Villingen-Schwenningen

Telefon +49 (0)7720 9712-0
Telefax +49 (0)7720 9712-9901

E-Mail info@carl-valentin.de
Internet www.carl-valentin.de


WIRING PLANS	1
Electronics	1
Mechanics	2
CPU (70.40.010).....	3
Plan of components.....	3
Jumper plan	4
Components and plug-in positions	4
CPU (70.40.201).....	5
Plan of components.....	5
Jumper plan	6
Components and plug-in positions	6
POWER UNIT (REVISION B).....	7
Plan of components.....	7
Components and plug-in positions	7
MEMORY CARD SLOT	8
Plan of components.....	8
Components and plug-in positions	9
COMPACT FLASH CARD SLOT.....	10
Plan of components.....	10
INPUT/OUTPUT PLATE.....	11
Plan of components.....	11
Jumper plan	12
Components and plug-in positions	12
ETHERNET (OPTION)	13
Plan of components.....	13
Components and plug-in positions	13
DISTRIBUTOR PLATE	14
Plan of components.....	14
Plug-in positions	14
VIEWS	15
Front view	15
Rear.....	16

MEASURING POINTS POWER UNIT	17
Voltage supply	17
Printhead voltage*	18
Printhead voltage*	18
Transformer voltage*	18
Feed motor	19
Feed motor	19
Ribbon motor	20
MEASURING POINTS CPU	21
Voltage supply	21
Clock Signal: RESET	21
Clock Signal: Systemclock	22
Printhead signals	23
MEASURING POINTS PHOTOCELLS	24
Transfer ribbon control photocell (TCR)	24
Printhead locking	25
Printhead control	25
EXCHANGE OF DEFECTIVE COMPONENTS	26
Exchange of fuse	26
CPU	28
Printhead FPGA*	29
Input/Output FPGA*	29
Batterie*	29
Power unit	30
Memory card slot	31
Input/output plate	32
INPUTS AND OUTPUTS	33
Control inputs and outputs (version I)	33
Control inputs and outputs (version II)	37
OPTIONS	41
Refit RS-485 and RS-422 plate	41
Refit Ethernet plate	42
Refit external rewinder	43


MECHANICS	44
Exchange of printhead Flat Type KF	44
Adjustment of printhead Flat Type KF	45
Exchange of printhead Corner Type KCE	47
Adjustment of printhead Corner Type KCE	48
Adjust rewinder / unwinder	50
Exchange pressure roll	51
Exchange / clean label photocell	52
Adjust pressure curve of ribbon savings	53
Adjust rail of ribbon savings	55
Oil and Lubricate	56
CONNECTION PLAN OF BACK PANEL PLUGS	57
Motors	57
Printhead signals	57
Sensors	58
CONNECTION PLAN INTERFACES	59
Centronics	59
RS-232	59
RS-485 and RS-422	60
Ethernet	61
INDEX	63

WIRING PLANS

Electronics




Mechanics



CPU (70.40.010)

Plan of components



Jumper plan

	JP1	JP2	JP3	JP4
BOOT	1-2	open	closed	1-2
STANDARD	2-3	open	open	1-2

	JP5	JP7	JP8	JP9
BOOT	closed	open	2-3	2-3
STANDARD	closed	closed	2-3	2-3

Components and plug-in positions

Components:


P1	Sensibility label photocell transmission
P2	Sensibility label photocell reflexion
P3	Sensibility dispenser photocell
U1; U2	FLASH component
U3	32bit RISC processor
U5; U6	DRAM
U8	RESET component
U10	RTC
U11	INPUT/OUTPUT FPGA
U13	RS-232 component
U14	USB component
U20	Printhead FPGA
U28	serial EEPROM

Plug-in positions

ST1	Bus plug
ST5	Connected sensor signals
ST13	Connection to power unit
ST15	Ribbon control
ST16, 17, 19	Dispensing I/O, RS-485, RS-422 (option)
ST20	Memory Card
ST21	Foil keyboard
ST22	Printhead KCE107/12 or KCE 162/12
ST24	LCD display

CPU (70.40.201)

Plan of components



Jumper plan

	JP1	JP2	JP3	JP4	JP5	JP6	JP7
BOOT	1-2	open	closed	1-2	closed	open	open
STANDARD	2-3	open	open	1-2	closed	open	closed *
2 Ladekanäle	2-3	open	open	1-2	closed	closed	closed *

	JP8	JP9	JP10	JP11	JP12	JP13	JP14
BOOT	1-2	1-2	-	1-2	1-2	open	open
STANDARD	2-3	2-3	2-3	1-2	1-2	open	1-2*
2 Ladekanäle	2-3	2-3	1-2	2-3	2-3	closed	1-2*

* If PCMCIA interface is used, JP7 open and JP14 2-3

Components and plug-in positions

Components:


U1; U2	FLASH component
U3	32 Bit RISC CPU
U5; U6	DRAM
U8	RESET
U10	RTC (Real Time Clock)
U11	Input/Output FPGA
U13	RS-232
U14	USB (Universal Serial Bus)
U20	Printhead FPGA

Plug-in positions

ST1	Bus male connector
ST5	Combined sensor signals
ST9	Zero point photocell
ST10	Limit point photocell
ST11	Cover switch
ST12	Compressed air control
ST13	Connection to power unit
ST15	Transfer ribbon control
ST16, 17, 19	Dispenser I/O, RS-485, RS-422 (option)
ST20	PCMCIA Card
ST21	Foil keyboard
ST22	Printhead KCE107/12 and KCE 53/12
ST24	LCD display
ST26	Compact Flash Card

POWER UNIT (REVISION B)

Plan of components



Components and plug-in positions

Components:

- U7 motor driver transfer ribbon motor
- U13 motor driver feed motor
- U16 control component printhead heater voltage
- U17 voltage control 5V
- U18 voltage control 24V
- Z1 Bridge-connected rectifier
- F1 secondary fuse 10A/T
- T2 P canal MOS-FET 100V/50A printhead voltage

Plug-in positions


- ST1 motor plug 'winder'
- ST3 motor plug transfer ribbon motor
- ST4 motor plug ribbon savings motor
- ST5 motor plug feed motor
- ST6 heater voltage printhead
- ST7 toroidal transformer
- ST8 cutter photocell (option)
- ST9 connection to CPU
- ST10 fan

Measuring values

- 5V voltage for CPU VCC
- 24V heater voltage printhead VDK
- 40V input voltage VIN
- GND mass

MEMORY CARD SLOT

Plan of components



Components and plug-in positions

Components:


- U3 data bus driver
- Q1 switching transistor for memory card voltage

Plug-in positions:

- JP1 connection to CPU

COMPACT FLASH CARD SLOT


Plan of components



If PCMCIA interface is used, JP7 open and JP14 2-3

INPUT/OUTPUT PLATE

Plan of components



Jumper plan

Only valid for complete equipped I/O plate

Function	Jumper position JP6
RS-422 full duplex	2-1
RS-485 half duplex	2-3

Components and plug-in positions

Components:


U1	EPLD component
U2	Optocoupler outputs 1-4 (Output1)
U3	Optocoupler outputs 5-8 (Output2)
U4	Optocoupler inputs 1-4 (Input1)
U5	Optocoupler inputs 5-8 (Input2)
U6	driver inputs
U7	Driver RS-422 / RS-485
U8	Optocoupler DTR/DIR
U9	Optocoupler TXD1
U10	Optocoupler RXD1
U11	Voltage transformer 5V → ±5V
U20, 21	Interface component RS-422 / RS-485

Plug-in position:

ST1	Outputs 1-4 (Output1)
ST2	Outputs 5-8 (Output2)
ST3	Inputs 1-4 (Input 1)
ST4	Inputs 5-8 (Input2)
ST5	RS-485 / RS-422
ST 16, 17, 19	Connection to CPU

ETHERNET (Option)

Plan of components



Components and plug-in positions

Components:


- U1 ethernet processor
- U5 reset inverter
- U6 voltage control 3.3V
- TR1 transformer

Plug-in positions:

- ST1 connection bus plug CPU

DISTRIBUTOR PLATE

Plan of components



Plug-in positions

ST3	Transfer ribbon motor
ST5	Feed motor
ST15	Transfer ribbon control
ST22	Motor signals of electronic
ST23	Printhead signals of electronic
ST24	Sensor signals of electronics
ST26	KCE 107/12
ST28	Motor signals
ST29	Printhead signals


VIEWS

Front view



	Printhead is moved up.
	Printhead is moved down.
	If available, you switch to the next edit field. With the arrow keys and you can change the values.
	If available, you switch to the next edit field. With the arrow keys and you can change the values.
	If you are in the Function Menu, you can switch to the next menu item.
	Switch to the Function Menu. If you are already in the Function Menu, you can switch one menu item back.
F1 - F2	No function
	Press this key to use the memory card function
	Switch to the Quantity Menu. With the arrow keys and you can select the number of labels you want to print.
	Settings in the Function Menu are confirmed. A current print order can be interrupted and then continued. In case the interrupted print order is not to continue, press the key to delete it. In this case no further label of the print order is printed.
	In case you are not in the Main Menu you can return to it. If you are in the Main Menu, a test print is released.

Rear



- A = Output 1
- B = Input 1
- C = USB
- D = Output 2
- E = Input 2
- F = Centronics
- G = RS-232
- H = Ethernet (option)
- I = Connection to PC keyboard
- J = Connection to heater voltage
- K = Connection to motor signals
- L = Connection to printhead data
- M = Connection to sensor signals
- N = Power connection (fuse 3,15A/T)

MEASURING POINTS POWER UNIT

Voltage supply

Attention: Unplug the machine!
Only experienced staff is allowed to open the machine and to proceed measuring.

The main measuring points are between ST3 (cut sensor) and SST7 (transformer input)

Measuring point	Description	Correct value	Notes
5V	VCC	5V	
24V	VDK		The printhead voltage depends on 3 factors (see below)
40V	VIN	40V	
GND	GND	0V	

1. factor = Contrast (the higher the contrast, the higher the printhead voltage)
2. factor = Printhead resistance (the higher the resistance, the higher the printhead voltage)
3. factor = Printhead temperature (the higher the temperature, the lower the printhead voltage)

Printhead voltage*

The printhead voltage depends on the following 3 factors:

1. factor = Contrast (the higher the contrast, the higher the printhead voltage)
2. factor = Printhead resistance (the higher the resistance, the higher the printhead voltage)
3. factor = Printhead temperature (the higher the temperature, the lower the printhead voltage)

The measured voltages are approximate values and therefore fluctuations from machine to machine can be possible:

Contrast	Measured printhead voltage printhead voltage: 1265 printhead temperature: 22°C	Measured printhead voltage printhead voltage: 1330 printhead temperature: 22°C
10%	≈ 22,78V	≈ 23,26V
100%	≈ 23,69V	≈ 24,17V
200%	≈ 24,66V	≈ 25,15V

Tranformer voltage*

Measuring point	Description	Correct value	Notes
ST7 PIN1 und 4; PIN2 und 3	28V1 /28V2	~ 30V	voltage alternating current VAC


*** Attention:** Unplug the machine!
Only experienced staff is allowed to open the machine and to proceed measuring.

Feed motor

Attention: Unplug the machine!
Only experienced staff is allowed to open the machine and to proceed measuring.

Measuring point	Description	Correct value	Notes
ST9 PIN28; D18 anode	FD_EA		release motor driver phase A
ST9 PIN31; D19 anode	FD_EB		release motor driver phase B
ST9 PIN32; R106	FD_C		control input motor current
ST9 PIN19; D17 anode	FD_PA		input signal motor driver phase A
ST9 PIN33 D20 anode	FD_PB		input signal motor driver phase B
ST9 PIN30 U15 PIN1 or PIN13	SYNC	≈ 28kHz	synchronisation motor driver

Schematic drawing of feed signals




Ribbon motor

Attention: Unplug the machine!

Only experienced staff is allowed to open the machine and to proceed measuring.

Measuring point	Description	Correct value	Notes
ST9 PIN11; D10 anode	RFD_EA		release motor driver phase A
ST9 PIN14; D11 anode	RFD_EB		release motor driver phase B
ST9 PIN12; R48	RFD_C		control input motor current
ST9 PIN9; D09 anode	RFD_PA		input signal motor driver phase A
ST9 PIN13; D12 anode	RFD_PB		input signal motor driver phase B
ST9 PIN30 U9 PIN1 or PIN13	SYNC	≈ 28kHz	synchronisation motor driver

Schematic drawing of ribbon motor



MEASURING POINTS CPU


Voltage supply

Attention: Unplug the machine!
 Only experienced staff is allowed to open the machine and to proceed measuring.

Measuring point	Description	Correct value	Notes
ST13 PIN 1/2 LED D3 anode	VCC	5V	
ST13 PIN 39/40	GND	0V	

Clock Signal: RESET


Attention: Unplug the machine!
 Only experienced staff is allowed to open the machine and to proceed measuring.




Correct value = 5V

Clock Signal: Systemclock

Attention: Unplug the machine!
Only experienced staff is allowed to open the machine and to proceed measuring.



Schematic drawing of system clock




Printhead signals

Attention: Unplug the machine!
 Only experienced staff is allowed to open the machine and to proceed measuring.

Measuring point	Description	Correct value	Notes
ST22 PIN5	DATAIN		
ST22 PIN7	CLOCK		
ST22 PIN9	/LATCH		
ST22 PIN11	B.E.O.		
ST22 PIN12-13	STR1-2		
ST22 PIN14-18	/CONT1-5		
ST22 PIN20	THERM	23°C ≈ 2,5V	the higher the voltage, the higher the temperature
ST22 PIN3, 4, 6, 8, 10, 19	GND		
ST22 PIN1, 2	5V		

Schematic drawing of printhead signals



MEASURING POINTS PHOTOCELLS

Attention: Unplug the machine!
Only experienced staff is allowed to open the machine and to proceed measuring.

The photocell signals (function in brackets) are central transmitted from the CPU by ST5 to the print mechanics. TCR (transfer ribbon control), HEADCLOSE (printhead locking) and HEADDOWN (printhead control).

Transfer ribbon control photocell (TCR)

Measuring point electronics CPU	Description	Correct value	Notes
ST15 PIN1	VCC	5V	
ST15 PIN2	RIBBONCTRL	H or L	
ST15 PIN3	PULLUP	≈ 1,297V	
ST15 PIN4	GND	0V	

Measuring point mechanics distributor plate	Description	Correct value	Notes
ST15 PIN1	VCC	5V	
ST15 PIN2	RIBBONCTRL	H or L	
ST15 PIN3	PULLUP	≈ 1,297V	
ST15 PIN4	GND	0V	

The transfer ribbon photocell checks the movement of transfer ribbon by changing of high and low value at RIBBONCTRL. The ration of the changing should be 1 to 1.
Is the value for a certain period static (H or L, but depending on the set power of the control) appears an error message.

The transfer ribbon control value is indicated in the service function menu as 'TR'

Printhead locking

Measuring point electronics CPU	Description	Correct value	Notes
ST11 PIN1	HEADCLOSE	H or L	
ST11 PIN2	GND	0V	

Measuring point mechanics distributor plate	Description	Correct value	Notes
ST11 PIN2	HEADCLOSE	H or L	
ST11 PIN4	GND	0V	

In case the printhead is closed, the photocell changes the HEADCLOSE signal to 0V. If the printhead is opened during printing the feed stops and the printhead voltage is immediately stopped.

The HEADCLOSE value is indicated in the service function menu as 'H'
(display '0' = printhead is closed).

Printhead control

Measuring point electronics CPU	Description	Correct value	Notes
ST12 PIN1	HEADDOWN	H or L	
ST12 PIN2	GND	0V	


Measuring point mechanics distributor plate	Description	Correct value	Notes
ST12 PIN2	HEADDOWN	H or L	
ST12 PIN4	GND	0V	

EXCHANGE OF DEFECTIVE COMPONENTS

Exchange of fuse

Primary fuse

Attention: Unplug the machine!
Only experienced staff is allowed to open the machine and to exchange defective components.




The primary fuse is into the line filter block (A).

Unplug the machine and then open its cover (B).

Remove the fuse-holder (C) which is behind to exchange the fuse (fuse value = 3,15A/T).

Secondary fuse

Attention: Unplug the machine!
Only experienced staff is allowed to open the machine and to exchange defective components.




After removing the machine cover the CPU plate is visible.

The secondary fuse which you can find onto the power unit is at the side.

F1: fuse 10A/T protection of the complete power unit voltage

CPU

Attention: Unplug the machine!
Only experienced staff is allowed to open the machine and to exchange defective components.



- Remove the machine cover.
- Disconnect the input/output plate at the power unit.
- Disconnect all line from the CPU.
- Unscrew the fixing screws (A) at the Centronics port.
- Unscrew the fixing screws (B) at the CPU.
- Remove the defectice CPU.
- Install the new CPU in reverse order.
- Install again the machine cover.

Printhead FPGA*

(see illustration (C) at the previous page)

Remove the defective FPGA from the PLCC support base with a suitable displacement pincer.

Pay attention to the poles and press the new FPGA into the support base.

Input/Output FPGA*

(see illustration (D) at the previous page)

Remove input/output plate from CPU and you can see the I/O FPGA.

Remove the FPGA from the PLCC support base with a suitable displacement pincer.

Batterie*

(see illustration (E) at the previous page)

Caution: Danger of explosion when exchanging the battery improper.
Use the same type of battery of an equivalent type which is recommended from the manufacturer.
Disposal of used battery according to specification of manufacturer.

Lift up the fixing bracket of battery.

Remove the defective battery.

Insert a new battery into the bracket.


Pay attention to the poles.

The battery is necessary for the current supply of real time clock (RTCF). After changing the battery, enter the Device Settings menu and switch to the menu item Date/Time to set them new.

*** Attention:** Unplug the machine!
Only experienced staff is allowed to open the machine and to exchange defective components.
Only experienced staff with corresponding tools is allowed to remove the FPGA!
Damages of PLCC support base must be avoided because the faultless function is no longer guaranteed.

Power unit

Attention: Unplug the machine!
Only experienced staff is allowed to open the machine and to exchange defective components.



Remove the machine cover.

Disconnect all lines.

Unscrew the fixing screws (A) at the rectifier Z1.

Unscrew the fixing screws at the base of electronics.

Remove the defective power unit.

Insert the new power unit into the electronics.

Please pay attention that no lines are clamped under the heat sink of power unit.


Connect again all lines to the appropriate plug-in positions.

Screw the new power unit.

Install again the machine cover.

Memory card slot

Attention: Unplug the machine!
Only experienced staff is allowed to open the machine and to equip the machine with options.



Remove the machine cover.

Disconnect the connecting cable (A) to CPU at break-through.

Unscrew the fixing screws (B) at the side panel.


Remove the defective slot (C).

Install the new slot in reverse order.

Install again the machine cover.

Input/output plate

Attention: Unplug the machine!
Only experienced staff is allowed to open the machine and to equip the machine with options.



- Remove the machine cover.
- Disconnect the connecting cable of input/output plate to the rear of machine.
- Remove the defective plate (A) carefully from CPU.
- Install the new plate.
- Connect the connecting cable according to the wiring plan.
- Install again the machine cover.
- Enter the service functions menu to test inputs and outputs.


```
Input:  11111111
Output: 00000000
```

In case an input is activated then the corresponding position changes to 1. If you want activating an output you have to move the cursor to the corresponding position and to set the value by means of the ▲ and ▼ key to 1. Set the value to 0 to deactivate an output.

Inputs and Outputs

Control inputs and outputs (version I)

Plug connection - back side of control unit



- A = External output 1-4 (Output I)
- B = External input 1-4 (Input I)
- C = External output 5-8 (Output II)
- D = External input 5-8 (Input II)

Control outputs


By means of the signal outputs different operating states of the print module can be queried.

The signal outputs are provided by two 9-pin SUB-D-bushings (OUTPUT I and OUTPUT II) on the back side of the control unit.

They consist of optocoupler semiconductor sections, which are connected through and/or blocked according to different operating states.

The maximum allowable current in a semiconductor section is $I_{max} = 30 \text{ mA}$.


Output I
Illustration above, A



PIN (bushing)	Output I
	Out 1: Error message Each error status such as ribbon error is displayed.
	Out 2: Print order The print module was activated by a print order.
	Out 3: Generation The print module is filled with current layout data.
	Out 4: Layout print The content of print memory is transferred on the printable medium by means of the printhead.


Example:

Connection of a lamp to a 24V relay by Out 1:



Output II

Illustration on page 54, C




PIN (bushing)	Output II
<p>9 (+) 5 (-)</p>	<p>Out 5: Print-Ready signal</p> <p>It is indicated if the print module is ready to process a start impulse. In contrary to the print order signal, the generating time is taken into consideration.</p>
<p>8 (+) 7 (-)</p>	<p>Out 6: Printhead up</p> <p>The printhead has reached the upper rest position (e.g. return to zero point).</p>
<p>6 (+) 2 (-)</p>	<p>Out 7: Return to start</p> <p>After termination of print procedure the flexible part of the print module is moved back to the start position. After the start position was reached a new start can be released.</p>
<p>4 (+) 3 (-)</p>	<p>Out 8: Prior warning of transfer ribbon end</p>

Control inputs

By means of the control inputs it is possible to control printing. The control inputs at Input I are galvanic separated and have to be provided with an external tension source. The signal level is active "HIGH".


Input I
Illustration on page 54, B




PIN (pin)	Input I
	In 1: Print start
	In 2: Not used
	In 3: Reset external counter
	In 4: Not used

Example

Connection of a switch with 24V voltage supply by In 1:




Input II
 Illustration on page 54, D



PIN (pin)	Input II
	In 5: Not used
	In 6: Not used
	In 7: Not used
	In 8: Not used

Control inputs and outputs (version II)

Plug connection - back side of control unit



- A = External output 1-4 (Output I)
- B = External input 1-4 (Input I)
- C = External output 5-8 (Output II)
- D = External bushing 15pin (I/O-24)

Control outputs

By means of the signal outputs different operating states of the print module can be queried.


The signal outputs are provided by two 9-pin SUB-D-bushings (OUTPUT I and OUTPUT II) on the back side of the control unit.

They consist of optocoupler semiconductor sections, which are connected through and/or blocked according to different operating states.

The maximum allowable current in a semiconductor section is $I_{max} = 30 \text{ mA}$.

Output I


Illustration above, A



PIN (bushing)	Output I
	Out 1: Error message Each error status such as ribbon error is displayed.
	Out 2: Print order The print module was activated by a print order.
	Out 3: Generation The print module is filled with current layout data.
	Out 4: Layout print The content of print memory is transferred on the printable medium by means of the printhead.


Example:

Connection of a lamp to a 24V relay by Out 1:



Output II

Illustration on page 58, C




PIN (bushing)	Output II
<p>9 (+) 5 (-)</p>	<p>Out 5: Print-Ready signal</p> <p>It is indicated if the print module is ready to process a start impulse. In contrary to the print order signal, the generating time is taken into consideration.</p>
<p>8 (+) 7 (-)</p>	<p>Out 6: Printhead up</p> <p>The printhead has reached the upper rest position (e.g. return to zero point).</p>
<p>6 (+) 2 (-)</p>	<p>Out 7: Return to start</p> <p>After termination of print procedure the flexible part of the print module is moved back to the start position. After the start position was reached a new start can be released.</p>
<p>4 (+) 3 (-)</p>	<p>Out 8: Prior warning of transfer ribbon end</p>

Control inputs

By means of the control inputs it is possible to control printing. The control inputs at Input I are galvanic separated and have to be provided with an external tension source. The signal level is active "HIGH".


Input I
Illustration on page 58, B



PIN (pin)	Input I
	In 1: Print start
	In 2: Not used
	In 3: Reset external counter
	In 4: Not used


Example

Connection of a switch with 24V voltage supply by In 1:



External bushing I/O-24

Illustration on page 58, D




This input is executed as 15-pole and provides user-sided 24V/100mA.

In case of using this bushing, exists **no galvanic separation**.


PIN	Function
1, 6	Gnd
5, 10	24 V / 100 mA
3	Print start (NPN initiator)
2	Print start (PNP initiator)
4	Print start by potential-free contact
14	
7	Signal lamp 24 V / 100 mA (error)
13	

Example 1




Connection scheme for creating a start signal by a sensor with NPN output

Example 2



Connection scheme for creating a start signal by a sensor with PNP output

Example 3




Connection scheme for creating a start signal by a potential-free contact

Connection of a signal lamp at error output (24 V/max. 200 mA)

OPTIONS

Refit RS-485 and RS-422 plate

Attention: Unplug the machine!
Only experienced staff is allowed to open the machine and to equip the machine with options.



Remove the machine cover.

Replace the already existing input/output plate (A) by a plate with either RS-485 or RS-422 extension.

Replace line to INPUT2 by a line with 9pin DSUB socket.


Connect the new line in plug-in position ST5 onto the input/output plate.

Connect OUTPUT1, INPUT1 and OUTPUT2 according wiring plan.

Install again the machine cover.

Refit Ethernet plate

Attention: Unplug the machine!
Only experienced staff is allowed to open the machine and to equip the machine with options.



Remove the machine cover.

Remove cover at break-through (A).

Unscrew fixing screw (B).

Screw the distance bolt M3x15 at this position.


Guide the Ethernet plate (A) into the break-through (A) and connect the plate to ST1 onto CPU.

Fix the plate with the previously removed screw (B) at the distance bolt.

Install again the machine cover.

Refit external rewinder

Attention: Unplug the machine!
Only experienced staff is allowed to open the machine and to equip the machine with options.



Guide the 9pin DSUB plug (A) of the rewinding unit (B) into the appropriate bushing at the side panel of the print mechanics.


Fix the rewinding unit with the appropriate thread of the supporting plate (C) at a plate or strut of your choice.

Please note that the position of disc (D) agrees with the label edge at the unwinding unit.

MECHANICS

Exchange of printhead Flat Type KF

Attention: Unplug the printer!



Note: Please note that you have to observe the ESD regulations for the exchange of printhead!
Do not touch the contacts of printhead!

Open cover of print module.

With closed printhead, loosen screws (A) by means of an Allen key (SW 2.5).

In order to open printhead, turn the right lever (B) anticlockwise (left version, in clockwise direction).

Now printhead should be situated freely onto pressure roll. Otherwise you have to loosen again screws (A).

Move printhead carefully to the front until you can reach the connectors.


Press clip onto right connector in order to remove connector. Remove the left connector carefully and remove afterwards the printhead.

Unscrew knurled knob (E) in order to remove aluminium intermediate plate (D) of printhead.

Note resistance value (R = xxx) that is find onto type plate of new printhead.

By means of knurled knob (E) mount the aluminium intermediate plate (D) onto new printhead.

Install the new thermal printhead in reverse order.



When re-installing the printhead, please take care that printhead locks in printhead bracket.

Close printhead, tighten again screws (A) and switch print module on.

Control position of printhead by means of a test print. In case the print quality does not come up to your expectation, set parallelism as described as followed.

In case the resistance value onto the type plate of the printer is different from the value of the old printhead, enter the service functions menu of the printer and enter the correct value (dot resistance).

Note: Improper handling is difficult to prove and therefore the producer does not grant guarantee for the printhead.

Adjustment of printhead Flat Type KF

Parallelism

An important characteristic for a high quality print is the parallelism of the focal line of the thermal printhead to the pressure roll. Because of the fact that the position of focal line of the printhead depends on fluctuations caused by production, it is necessary to set the parallelism.

By means of a hexagon key unscrew the screws (D) by approx. $\frac{1}{4}$ turn.

With the adjusting screws (E) it is possible to set the parallelism.

Turn in clockwise direction and the printhead moves backwards.

Turn anticlockwise and the printhead moves forwards.

Depending on the print quality of the test print, turn the screws as long as the print quality comes up to your full expectation.

Screw again the screws (D).

Start a print order with approx. 5 to 10 labels and control the correct and wrinkle free ribbon. In case of wrinkles then you have again to check parallelism.

Pressure balance right/left

After adjusting parallelism and no even strong pressure exists over the complete print width, by means of a plate (F) you can set the balance as follows:

Unscrew with a screwdriver the screw (G) by approx. $\frac{1}{4}$ turn.

By means of an excentric pin (H) you can create by turning a balance of pressure.

Adjust the printing corresponding to the test print as long as this results in an even printing.

Screw again screw (G).

Start a print order with approx. 5 to 10 labels and control the correct and wrinkle free ribbon. In case of wrinkles then you have again to check parallelism or balance of pressure.

Pressure

Note: It is recommended to avoid increasing the printhead pressure because too high pressure damages the printhead res. reduces its life.

The pressure is set from the manufacturer according to the specification of the printhead.

It is possible to optimise the life of the printhead by selecting the lowest possible setting.

By means of pressure screws (I) you can modify the printhead pressure without tools.


If the pressure screws are turned in clockwise direction to the end, then the pressure is increased by 10N in contrast to the factory setting.

If you want to set the factory setting then you have to turn the pressure screws by the right side exactly by 1 turn anticlockwise.

It is importantly that the knurled button which is coated with protective lacquer is not removed from the pressure screw as otherwise the above mentioned settings are faulty.

Exchange of printhead Corner Type KCE

Attention: Unplug the printer!



Note: Please note that you have to observe the ESD regulations for the exchange of printhead!
Do not touch the contacts of printhead!

Open print module cover.

Close the printhead, then unscrew the knurled screws (A) by means of an Allen key 2,5.

Move the printhead up by turning the red lever (B) anticlockwise.

Now the printhead (C) should be freely onto the pressure roll (otherwise unscrew again the knurled screws).

Remove the thermal printhead carefully to the front until you have access to the connectors.

Press clip onto right connector in order to remove connector. Afterwards remove left connector carefully and remove printhead.

Note the resistance value which you can find on the type plate of the new printhead and install the new thermal transfer printer in reverse order.

When re-installing pay attention that printhead locks in printhead bracket.

Close printhead and tighten again screws (A) and then switch on the printer.

Control the position of printhead by means of a test print. In case the print quality does not come up to your expectation, set the parallelism as following described.

In case the resistance value onto the type plate of the printer is different from the value of the old printhead, enter the service functions menu of the printer and enter the correct value (dot resistance).

Note: Improper handling is difficult to prove and therefore the producer does not grant guarantee for the printhead.

Adjustment of printhead Corner Type KCE

Parallelism

An important characteristic for a high quality print is the parallelism of the focal line of the thermal printhead to the pressure roll. Because of the fact that the position of focal line of the printhead depends on fluctuations caused by production, it is necessary to set the parallelism.

The form of the printhead KCE needs the setting of parallelism in direction of the adjusting angle and in horizontal position. It needs a little bit of experience to know in which direction you have to adjust the printhead to receive a high quality printing.

Unscrew the screws (A or D) by approx. $\frac{1}{4}$ turn by means of a hexagon key 2,5.

With the adjusting screws (E or I) it is possible to set the parallelism.
Turn in clockwise direction and the printhead moves backwards.
Turn anticlockwise and the printhead moves forwards.

Depending on the print quality of the test print, turn the screws as long as the print quality comes up to your full expectation.

Screw again the screws (A or D).

Start a print order with approx. 5 to 10 labels and control the correct and wrinkle free ribbon. In case of wrinkles then you have again to check parallelism.

Pressure balance right/left

After adjusting parallelism and no even strong pressure exists over the complete print width, by means of a plate (F) you can set the balance as follows:

Unscrew with a screwdriver the screw (G) by approx. $\frac{1}{4}$ turn.

By means of an excentric pin (H) you can create by turning a balance of pressure.

Adjust the printing corresponding to the test print as long as this results in an even printing.

Screw again screw (G).

Start a print order with approx. 5 to 10 labels and control the correct and wrinkle free ribbon. In case of wrinkles then you have again to check parallelism or balance of pressure.

Pressure

Note: It is recommended to avoid increasing the printhead pressure because too high pressure damages the printhead res. reduces its life.

The pressure is set from the manufacturer according to the specification of the printhead.

It is possible to optimise the life of the printhead by selecting the lowest possible setting.

By means of pressure screws (K) you can modify the printhead pressure without tools.


If the pressure screws are turned in clockwise direction to the end, then the pressure is increased by 10N in contrast to the factory setting.

If you want to set the factory setting then you have to turn the pressure screws by the right side exactly by 1 turn anticlockwise.

It is importantly that the knurled button which is coated with protective lacquer is not removed from the pressure screw as otherwise the above mentioned settings are faulty.

Adjust rewinder / unwinder

Attention: Unplug the machine!
Only experienced staff is allowed to open, repair and adjust the machine.



Due to the many different transfer ribbon variants regarding roll width, length and qualities it is necessary to provide the possibility to set transfer ribbon tension.

The transfer ribbon tension is to set in such way that no wrinkles in the ribbon appear but it is transported in the same way as the labels.

When using a too high ribbon tension this results usually in an excellent run of the transfer ribbon but this could lead to streaks onto the label or to a rip of ribbon particularly with narrow roles.


Ex factory the role tension is set to a transfer ribbon 110 mm width and standard quality. As approximate values for the factory setting the following can be accepted:

Unwinder: distance of screw head (A) to roll face (B) = 2 mm
Rewinder: distance of screw head (A) to roll face (B) = 4 mm

Screw the hexsocket head screw (A) to increase the transfer ribbon tension.
Unscrew the hexsocket head screw (A) to reduce the transfer ribbon tension.

Exchange pressure roll

Attention: Unplug the machine!
Only experienced staff is allowed to open, repair and adjust the machine.



Remove cover at the rear of the print mechanics
Unscrew 2 screws at the rear and 3 at the connection side.

Open the printhead by turning the pressure lever (A) anticlockwise.

Unscrew the pins (B) from belt drive (C) of the pressure roll (D).

Remove the protective disc (E) and the ball bearing (F).

Push the pressure roll (D) through the drillings to the outside. During the process you have to keep the belt drive (C).

Install the new roll in reverse order.


When installing the belt drive (C) anew you have to make sure that a pin (B) have to meet the milled surface of roll axle. Screw again the pins (B) firmly.

The roll has to be very fix.


Install again the machine cover.

Exchange / clean label photocell

Attention: Unplug the machine!
Only experienced staff is allowed to open, repair, adjust and clean the machine.



A



B

C

Remove cover at the rear of the print mechanics
Unscrew 2 screws at the rear and 3 at the connection side.

Turn the knurled knob (A) anticlockwise until you can remove the photocell (B) from the straight shaft (C).

Disconnect the plugs (D) from the photocell.


Install the photocell in reverse order.

Make sure that when re-installing the photocell the support is in the middle of the break-through (E).
One-side tilting can cause a worse photocell level or label jam.

Install again the machine cover.

Adjust pressure curve of ribbon savings


Attention: Unplug the machine!
Only experienced staff is allowed to open, repair and adjust the machine.



In case the ribbon savings function is activated and you can note that the printhead does not move far away from the label material, it is necessary to adjust the pressure curve anew. This curve is situated onto the axle of the ribbon savings motor (A).

Remove cover at the rear of the print mechanics
Unscrew 2 screws at the rear and 3 at the connection side.

You can find a detailed description on the following page.



The illustration shows the axle of the ribbon savings motor (A) with pressure curve (B) and disc (C) from the rear. Underneath is the bush bearing (D) with sole plate (E).

Close the printhead.

Unscrew the hexsocket head screw (F) by approx. 1 turn until the sole plate (E) with the set ball bearing (G) is freely mobile.

Turn by hand the motor shaft with pressure curve and disc into the illustrated adjusting position.

Press the sole plate (E) with ball bearing (G) into the adjusting notch of the pressure curve, so that they are fix and no more play exists. Screw the hexsocket head screw (F) firmly.

Open the printhead.

Turn by hand the motor shaft with pressure curve and disc into the illustrated printing position.

Close the printhead.

Turn by hand the motor shaft with pressure curve and disc to the left and right, until you feel an easy resistance. If the slot in the disc moves in each case slightly on the right and on the left side from the photocell (H), the pressure curve is correctly adjusted.

If the gap should not be in the range of the photocell, the following causes are possible:

- For the adjustment the wrong notch onto the pressure curve was used.
- The pressure curve is rotated to the disc onto the motor shaft.
The gap of disc has to be exactly opposite the pressure position notch!

Connect the protective conductor at the inside of the machine cover.

Push the machine cover onto the chassis.

Switch the machine on.


By means of the ▲ and ▼ key it is possible to move the printhead up and down. In case you use very thick label material it could be possible that the printhead is not sufficiently moved up. There are the following possibilities to position the printhead correctly:

Repeat again the adjusting steps and place the label material during the work between printhead and roll.

Install again the machine cover.

Adjust rail of ribbon savings

Attention: Unplug the machine!
Only experienced staff is allowed to open, repair and adjust the machine.



In case at an activated ribbon savings function jamming of paper occur or the position of the print onto the label is not correct, then this could arise because of the wrong setting of rail (A).


If the printhead is moved up, the rail (A) in connection with the below placed transport roll is responsible for the label feed. The pressure of rail should correspond approximately to the one of the printhead. The work setting corresponds to an average for standard labels. For very narrow, extremely smooth or thick labels a deviating setting can be necessary.

By means of the pins (B) it is possible to change the pressure.
Screw the pins (B) and you can increase the pressure.
Unscrew the pins (B) you can decrease the pressure.

By means of test prints you can adjust the specific pressure you need for your application.

Oil and Lubricate

Attention: Unplug the machine!
Only experienced staff is allowed to open, repair, adjust and clean the machine.



Make sure when oiling and greasing that no lubricants deposit on photocells, electronic components, circuit boards, printhead and rolls.

In case that dust or other dirt is deposit you have to clean the lubrication at first with alcohol.


Apply rather in regular intervals (1-2 per year) a bit of lubricant, as only rarely too much. Otherwise the surplus of lubricant could settle on neighbouring components and disturb the functions.

In case that components should have run it because of lack of lubricant, exchange these as soon as possible so the functions of the components and the machine remain.

Install again all components which you have dismantled for the lubrication in the correct position. Take care e.g. tensions of belt, springs etc.


CONNECTION PLAN OF BACK PANEL PLUGS

Motors




PIN	Signal
1-2; 14-15	FEED motor
3-4, 16-17	HEAD Motor
5	24V
7-8; 19-20	RIBBON motor

Printhead signals



PIN	Signal
1, 14	5V
2, 10, 15-18	GND
3	DATAIN
4	CLOCK
5	/LATCH
6	B.E.O.
7	/STR2
8	/CONT2
9	/CONT4
19	/STR1
20	/CONT1
21	/CONT3
22	/CONT5
23	THERM

Sensors



PIN	Signal
2,8	GND
1-9	LABEL, PULLUP
10	5V
3, 11	RIBBONCTRL, PULLUP (transfer ribbon photocell)
6, 14	TCREND, PULLUP


CONNECTION PLAN INTERFACES

Centronics




PIN	Signal
1	STROBE
2-9	DATA1-8
10	ACK
11	BUSY
12	PERROR
13	SELECT
14	AUTOFD
15-16	GND
18	VCC1284 (4,7V)
19-30	GND
31	INIT
32	FAULT
33-35	XXX
36	SELECTIN

RS-232




PIN	Signal
1	XXX
2	RXD
3	TXD
4-5	GND
6-9	XXX

RS-485 and RS-422



PIN at D-SUB socket	Function RS-422 (full duplex)		Function RS-485 (half duplex)	
1	n/c		n/c	
2	n/c		n/c	
3	n/c		n/c	
4		TxD-	n/c	
5		TxD+	n/c	
6	n/c			TxD (RTxD)-
7	n/c			TxD (RxD)+
8		RxD-	n/c	
9		RxD+	n/c	

Ethernet



1

8

PIN RJ45-socket	Description	
1		TX+
2		TX-
3		RX+
4	n/c	
5	n/c	
6		RX-
7	n/c	
8	n/c	

Index

A

Adjust	
Pressure curve	53
Rail	55
Rewinder	50
Unwinder	50

B

Battery (exchange)	29
--------------------------	----

C

Centronics (connections)	59
CF card slot	
Plan of components	10
Clean (photocell)	52
Clock signal	
Reset	21
System clock	22
Components	
CPU	4, 6
Ethernet (option)	13
Memory card slot	9
Power unit	7
Connection plan	
Motors	57
Printhead signals	57
Sensors	58
Connections	
Centronics	59
Ethernet	61
RS-232	59
RS-422	60
RS-485	60
CPU	
Components	4, 6
Exchange	28
Jumper plan	4, 6
Plan of components	3, 5
Plug-in position	4, 6

D

Distributor plate	
Plan of components	14
Plug-in positions	14

E	
Electronics (wiring plan)	1
Ethernet (option)	
Components	13
Connections	61
Exchange	42
Plan of components	13
Plug-in positions	13
Exchange	
Battery	29
CPU	28
Ethernet plate	42
Fuses	26, 27
Input/Output FPGA	29
Input/output plate	32
Memory card slot	31
Photocell	52
Power unit	30
Pressure roll	51
Printhead (Corner Type)	48
Printhead (Flat Type)	44
Printhead FPGA	29
RS-422 plate	41
RS-485 plate	41
External rewinder (refit)	43
F	
Feed motor	
Measuring points	19
Schematic drawing	19
Front view	15
I	
Input/Output	
FPGA (exchange)	29
Plate (build-in positions)	12
Plate (exchange)	32
Plate (jumper plan)	12
Plate (plan of components)	11
Plate (plug-in positions)	12
Inputs/outputs	33, 34, 35, 36, 37, 38, 39, 40
J	
Jumper plan	
CPU	4, 6
Input/output plate	12
L	
Lubricate and oil	56

M

Measuring points (CPU)	
Clock signal reset.....	21
Clock signal system clock.....	22
Printhead signals (schematic drawing).....	23
Printhead voltage.....	23
System clock (schematic drawing).....	22
Voltage supply.....	21
Measuring points (photocells)	
Printhead control.....	25
Printhead locking.....	25
Ribbon control.....	24
Measuring points (power unit)	
Feed motor.....	19
Feed motor (schematic drawing).....	19
Printhead voltage.....	18
Ribbon motor (schematic drawing).....	20
Transformer voltage.....	18
Voltage supply.....	17
Mechanics (wiring plan).....	2
Memory card slot	
Components.....	9
Exchange.....	31
Plan of components.....	8
Plug-in positions.....	9
Motors (connection plan).....	57

O

Oil and lubricate.....	56
------------------------	----

P

Parallelism	
Corner Type.....	48
Flat Type.....	45
Photocell	
Clean.....	52
Exchange.....	52
Printhead control.....	25
Ribbon control.....	24
Plan of components	
CF card slot.....	10
CPU.....	3, 5
Distributor plate.....	14
Ethernet (option).....	13
Input/output plate.....	11, 12
Memory card slot.....	8
Power unit.....	7

Plug-in positions	
CPU.....	4, 6
Distributor plate.....	14
Ethernet (option).....	13
Input/output plate.....	12
Memory card slot.....	9
Power unit.....	7
Power unit	
Components.....	7
Exchange.....	30
Measuring values.....	7
Plan of components.....	7
Plug-in position.....	7
Pressure	
Balance (Corner Type).....	48
Balance (Flat Type).....	45
Curve (adjust).....	53
Roll (exchange).....	51
Set (Corner Type).....	49
Set (Flat Type).....	46
Primary fuse (exchange).....	26
Printhead	
Control (photocell).....	25
FPGA (exchange).....	29
Locking (photocell).....	25
Signals (connection plan).....	57
Signals (schematic drawing).....	23
Voltage.....	18
Voltage (CPU).....	23
Printhead (Corner Type)	
Exchange.....	48
Parallelism.....	48
Pressure.....	49
Pressure balance.....	48
Printhead (Flat Type)	
Exchange.....	44
Parallelism.....	45
Pressure.....	46
Pressure balance.....	45
R	
Rail (adjust).....	55
Rear (illustration).....	16
Rewinder (adjust).....	50
Ribbon Motor	
Schematic drawing.....	20
RS-232 plate (connections).....	59

RS-422 plate	
Connections	60
Exchange	41
RS-485 plate	
Connections	60
Exchange	41
S	
Secondary fuse (exchange).....	27
Sensors (connection plan).....	58
System clock (schematic drawing)	22
T	
Transfer ribbon control (photocell)	24
Transformer voltage	18
U	
Unwinder (adjust)	50
V	
Views	
Front view	15
Rear	16
Voltage supply	
CPU.....	21
Power unit plate	17
W	
Wiring plan (electronics).....	1
Wiring plan (mechanics).....	2



Carl Valentin GmbH
Neckarstraße 78 – 86 u. 94 . 78056 Villingen-Schwenningen
Phone +49 (0)7720 9712-0 . Fax +49 (0)7720 9712-9901
info@carl-valentin.de . www.carl-valentin.de